

PRIMO[®]
Deluxe
Bottom-
Loading
Water
Dispenser




CLEAN, MODERN,
COMPLEMENTS YOUR LIFESTYLE
B262

Deluxe Bottom-Loading Water Dispenser

#601256 B262

FEATURES



WATER DISPENSING CONTROLS

Dark Blue - Cold
Light Blue - Cool
Red - Hot

INDICATOR LIGHTS

Green light on ON icon
indicates the dispenser is plugged in.

Green light on snowflake
indicates the dispenser is cooling water.

Green light on wavy lines
indicates the dispenser is heating water.

Blinking red light on the bottle icon
indicates the bottle is empty.

SPOUTS – Right dispenses cold water, left dispenses hot water and center dispenses cool water.

LED NIGHTLIGHT – Helps in low light situations.

DRIP TRAY WITH FULL INDICATOR – Removable and dishwasher-safe. Red indicator rises when it's time to empty.

PROBE ASSEMBLY – Probe pumps water from the bottle into the hot and cold reservoirs.

PROBE HANGER – Rest probe assembly on the hanger (located inside the cabinet door) to keep it clean while replacing bottles.

BOTTOM LOADING DESIGN – Bottles fit inside bottom of cabinet for easy use.

WATER BOTTLE – Sold separately. Uses 11.3 and 18.9-liter bottles. Visit PrimoWater.ca to find Primo® water at the store nearest you.

QUICK START GUIDE


1. Place the dispenser on a level floor surface in the desired location in your home. Product is intended for indoor use only. [Note: Do NOT plug power cord into wall outlet until instructed.]




2. Position dispenser so the back is at least 4 inches from wall and there are at least 4 inches of clearance on both sides.




3. Slide drip tray into place.




4. Clean probe with a damp cloth and dish soap. (Visit PrimoWater.ca for detailed cleaning instructions.) Place probe assembly on hanger inside door to keep it clean.



5. Grab a bottle of Primo® water (sold separately) and fully remove the cap. Insert probe assembly into bottle. Press firmly to secure assembly over bottle opening. For 11.3-liter bottles, squeeze the tabs on the top of the probe assembly to separate the probe cap from the collar and press the collar securely over the bottle opening.




6. Slide bottle inside the cabinet and close cabinet door. [Note: Water will not pump from bottle unless door is fully closed.]



7. Plug dispenser into a ground fault circuit interrupting (GFCI) outlet. You will hear the dispenser begin to pump water to fill the internal hot and cold reservoirs.



8. Turn on desired functions by flipping the switches on the back of the dispenser to the ON position.
Green – chills water
Red – heats water
Blue – night light



9. Once the dispenser has stopped filling the internal reservoirs, dispense and dispose at least 1 quart (approximately 2 pint glasses) of water from the cold, cool, and hot spouts.



10. Your water will be ready to dispense fully chilled in approximately 1 hour or piping – hot in approximately 12 minutes.



11. Register your dispenser at PrimoWater.ca to activate your warranty, which runs for 1 year from date of purchase.

Primo® 18.9-Liter Bottled Water or Self-Service Refill Water (sold separately)



Available at numerous locations.
Find the store nearest you at PrimoWater.ca.

Deluxe Bottom-Loading Water Dispenser

OPERATING INSTRUCTIONS

DISPENSING COLD WATER

- Water will take approximately 1 hour after initial set up to become completely chilled. Cooling light will turn off once the water has been fully chilled.
- Press and hold the blue cold water button from the water dispensing controls to dispense cold water. Release to stop dispensing.
NOTE: Water will dispense from the right spout.

DISPENSING COOL WATER

- Press and hold the light blue cold water button from the water dispensing controls to dispense cool water. Release to stop dispensing.
NOTE: Water will dispense from the center spout.

DISPENSING HOT WATER

- Water will take approximately 12 minutes after initial set up to reach its hottest temperature. Heating light will turn off once the water has been fully heated.
- Slide the red child lock back, then press down and hold the button from the water dispensing controls to dispense hot water. Release to stop dispensing.
NOTE: Water will dispense from the left spout.

CAUTION: This unit dispenses water at temperatures that can cause severe burns. Avoid direct contact with hot water. Keep children and pets away from the unit while dispensing. Never allow children to dispense hot water without proper and direct supervision. Disable the heating feature by switching the heating convenience switch on the back of the unit to the off position or unplug the unit. Product is intended for water dispensing only. Do not use with other liquids.

LIMITED WARRANTY

Primo Water Corporation, ("Vendor") warrants to the original purchaser of this dispenser, and to no other person, that if this dispenser is assembled and operated in accordance with the printed instructions accompanying it, then for a period of one (1) year from the date of purchase, all parts in such dispenser shall be free from defects in material and workmanship. Vendor may require reasonable proof of your date of purchase from an authorized retailer or distributor. Therefore, you should retain your sales slip or invoice. The Limited Warranty shall be limited to repair or replacement of parts which prove defective under normal use and service and which Vendor shall determine in its reasonable discretion upon examination to be defective. Before returning any parts, you should contact Vendor's Customer Service Department using the contact information listed below. If Vendor confirms, after examination, a defect covered by this Limited Warranty in any returned part, and if Vendor approves claim, Vendor will replace such defective part without charge. If you return defective parts, transportation charges must be prepaid by you. Vendor will return replacement parts to original purchaser, freight or postage prepaid. For units purchased outside of the continental US (limited to Hawaii, Alaska, and Puerto Rico), dispensers determined to be defective by the Vendor should be returned or exchanged at the original point of purchase within the warranty period.

For warranty information, additional assistance, or instructional videos for maintaining or operating your dispenser, visit our customer support page at **PrimoWater.ca**.

Primo Water Corporation, 101 N. Cherry St. Suite 501, Winston-Salem, NC 27101

REPLACING THE BOTTLE

When your bottle is empty, the empty bottle light will flash. To prevent freeze-up or over-heating, the dispenser will not heat or cool water when the bottle light is flashing. Replace the bottle as soon as possible to re-enable cooling and heating.

- Open dispenser cabinet door and slide empty bottle out of cabinet.
- Remove probe assembly from the empty bottle and place it on the probe hanger.
- Set empty bottle aside.
- Remove the entire plastic cap from the new bottle.
- Place probe into the new bottle and slide the collar down until it clicks into place. Press on the top of the probe until the tube touches the bottom of the bottle. For 11.3-liter bottles, squeeze the tabs on the top of the probe assembly to separate the probe cap from the collar and press the collar securely over the bottle opening.
- Slide the bottle into the cabinet and close the door.

CLEANING & MAINTENANCE

For best taste, performance, and hygiene, clean your cabinet, controls, bottle probe and spouts regularly. Use a clean, soft cloth and food grade sanitizer or bleach.

Empty and clean drip tray as needed. Clean the cold reservoir regularly.

Visit **PrimoWater.ca** for detailed cleaning instructions.

The Limited Warranty does not cover any failures or operating difficulties due to accident, abuse, misuse, alteration, misapplication, improper installation or improper maintenance or service by you or any third party, or failure to perform normal and routine maintenance on the dispenser, as set out in the User's Manual. In addition, the Limited Warranty does not cover damage to the finish after purchase, including without limitation scratches, dents, discoloration or rust.

The Limited Warranty is in lieu of all other express warranties. Vendor disclaims all warranties for products that are purchased from sellers other than authorized retailers or distributors. AFTER THE PERIOD OF THE ONE (1) YEAR EXPRESS WARRANTY, VENDOR DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. FURTHER, VENDOR SHALL HAVE NO LIABILITY WHATSOEVER TO PURCHASER OR ANY THIRD PARTY FOR ANY SPECIAL, INDIRECT, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. Vendor assumes no responsibility for any defects caused by third parties. This Limited Warranty gives the purchaser specific legal rights; a purchaser may have other rights depending upon where he or she lives. Some jurisdictions do not allow exclusions or limitation of special, incidental or consequential damages, or limitations on how long a warranty lasts, so the above exclusion and limitations may not apply to you.

CHANGEMENT DE BOUTEILLE

- Quand la bouteille est vide, le voyant de bouteille vide clignote. Pour éviter le gel ou la surchauffe, le distributeur ne chauffe ni ne réfrigère l'eau quand le voyant de bouteille clignote. Changer la bouteille plus tôt possible pour rétablir le refroidissement et le chauffage.
- Ouvrir la porte du distributeur et extraire la bouteille vide de son logement.
- Retirer le tube d'aspiration de la bouteille vide et le mettre sur son support.
- Écarter la bouteille vide.
- Retirer de la bouteille pleine la totalité du bouchon en matière plastique.
- Mettre le tube d'aspiration dans la bouteille pleine et appuyer sur le collier jusqu'à ce qu'il s'enclenche en place. Appuyer sur le haut du tube jusqu'à ce qu'il touche le fond de la bouteille. Pour les bouteilles de 1.3 litres, séparer le bouchon du tube de son collier en appuyant sur les languettes en haut du tube d'aspiration, puis enfoncer le collier fermement sur le goulot.
- Mettre la bouteille dans son logement et fermer la porte.

NETTOYAGE ET ENTRETIEN

Pour conserver le goût, les performances et l'hygiène, nettoyer régulièrement les parois du distributeur, les commandes, le tube de prise d'eau et les robinets. Utiliser un chiffon doux propre et de l'assainisseur de qualité alimentaire ou de l'eau de Javel.

Vider et nettoyer le ramasse-gouttes au besoin. Nettoyer régulièrement le réservoir d'eau froide.

On trouvera des instructions de nettoyage détaillées sur le site **PrimoWater.ca**.

GARANTIE LIMITÉE

ATTENTION: Cet appareil distribue de l'eau à des températures pouvant causer des brûlures graves. Éviter tout contact direct avec l'eau chaude. Garder les enfants et les animaux à l'écart de l'appareil pendant l'écoulement de l'eau. Ne jamais laisser un enfant obtenir de l'eau chaude sans la supervision d'un adulte. Pour désactiver le chauffage de l'eau, mettre l'interrupteur de chauffage, à l'arrière de l'appareil, sur la position « OFF » (arrêt), ou débrancher le distributeur. L'appareil est prévu pour fonctionner uniquement avec de l'eau. Ne pas l'utiliser avec d'autres liquides.

1. Appuyer et maintenir l'appui sur le bouton bleu clair du distributeur pour obtenir de l'eau fraîche. Relâcher l'appui pour que l'eau atteigne sa température maximale.
2. Pousser le verrou de sécurité enfants vers l'arrière, puis appuyer sur le bouton et maintenir l'appui pour obtenir de l'eau chaude. Relâcher l'appui pour arrêter l'écoulement de l'eau.

DISTRIBUTION D'EAU CHAUDE

1. Appuyer et maintenir l'appui sur le bouton bleu clair du distributeur pour obtenir de l'eau froide. Relâcher l'appui pour arrêter l'écoulement de l'eau.
2. Appuyer et maintenir l'appui sur le bouton bleu du distributeur pour obtenir de l'eau froide. Relâcher l'appui pour que l'eau atteigne sa température maximale.

DISTRIBUTION D'EAU FRAÎCHE

1. Appuyer et maintenir l'appui sur le bouton bleu du distributeur pour obtenir de l'eau froide. Relâcher l'appui pour arrêter l'écoulement de l'eau.
2. Appuyer et maintenir l'appui sur le bouton bleu du distributeur pour obtenir de l'eau froide. Relâcher l'appui pour que l'eau atteigne sa température maximale.

DISTRIBUTION D'EAU FROIDE

MODE D'EMPLOI

Distributeur d'eau à chargement par le bas – modèle de luxe

PROPRE, MODERNE, CONVIENT
À VOTRE MODE DE VIE
B262



PRIMO®
Distributeur
d'eau à
chargement
par le bas -
modèle de
luxe