

Placement of your New Dispenser


The placement of the dispenser must be indoors.

Placement location should be away from direct sunlight and excessive heat, cold and moisture.




Place dispenser in a well-ventilated area.

Please allow a minimum of 4 inches from the wall for proper function of the condenser coil located on the back of the dispenser.



Place dispenser on a flat and stable surface.

Unbalanced placement may cause excessive noise and/or shaking of the unit.



Avoid harmful gas or excessive heat.

Placement of the dispenser should be in an area free from gases and excessive heat sources.



2

Installation Procedures

Verify that the white cold water baffle is securely in place before placement of water bottle.

If the cold water baffle is removed, water will not be cooled. Remove plastic cap on water bottle, turn bottle upside-down filling the stainless steel tank visible inside the top of the dispenser.

Fill with bottled water only.


Filling with liquid(s) other than bottled water may cause significant problems in the dispenser.

To prepare your hot water function, depress the hot water valve until a steady stream of water is visible from the faucet. This purges air from inside the hot water tank.

Be sure to complete this step before connecting the dispenser to an electrical outlet, Supplying power to the hot water tank before fully purging air may cause damage.

The heating system can be turned on or off by the hot switch located on the back of the dispenser.

If you prefer room temperature water, simply turn off the heat switch and then you may dispense room temperature water from the hot water valve. (Please allow 24 hours for hot water to cool.)



Carefully connect the power cord into a grounded 110V electrical outlet.

3

Installation Procedures cont.

- Recommended use with a 15-20 amp circuit
- Ensure using a polarized, grounded, GFCI (Ground Fault Circuit Interrupter) power outlet
- Do not use with any type of plug adaptor or extension cord

For first time use, please allow a minimum of 30 minutes for water heating and 45 minutes for water cooling.

Operating your water dispenser

This water dispenser features two easy-to-use faucets.

The right faucet supplies chilled water ranging from 36°F to 50°F.

The left faucet supplies hot water ranging from 172°F to 185°F. To operate the child-resistant valve, squeeze the 2 levers on top of the faucet together lengthwise while activating.

This dispenser is equipped with a “child-resistant” hot water dispensing valve to help prevent injuries. Water from the hot water faucet is extremely hot and can cause injury. Children should not be allowed to operate the hot water faucet.

Your dispenser's hot and cold water settings have been preset at the factory. If you wish to adjust the cold water temperature setting, an adjustable thermostat control is located on the back of the dispenser. Using a small, flathead screwdriver, turn the adjusting screw clockwise to lower the water temperature or counter-clockwise to raise the water temperature. Make small adjustments(no more than a 1/4 turn)at a time until the desired temperature is achieved. Allow 24 hours between adjustments. No temperature adjustment is available for the hot water.

4

General Precautions

Use bottled water only

Filling the dispenser with any other type of liquid(s) may cause significant problems, and will void seller's warranty.

Keep the condenser free from dirt and dust

The cooling performance decreases when dirt and dust accumulate on the condenser.

Disconnect power and completely drain the hot water tank if the dispenser is not to be used for an extended period of time.

The hot water tank can be drained by removing the drain cap located on the back of the dispenser.

Disconnect the power cord from the outlet before cleaning, inspecting, or repairing the dispenser to prevent electrical shock.

Power interruption

When the power cord is disconnected, wait a minimum of 5 minutes before reconnecting. When power is temporarily turned off, disconnect the cord from the electrical outlet and wait a minimum of 5 minutes before power is reconnected after power is restored.

Capacities

Cold Water Reservoir- 1 Gallon
Hot Water Tank-.32 Gallon

5

Cleaning and Purifying your Dispenser

It's easy to keep your high-quality, two-temperature water dispenser in clean condition year round. Just keep several basic cleaning items on hand, and set aside a few minutes every 3-6 months(recommended).

Be sure to have the following items within easy reach before you begin cleaning your dispenser:

- Clean pair of rubber gloves
- Clean scrub brush or cleaning pad
- Paper towels
- Boiling water


Note: Always wait until the water bottle is empty before starting the cleaning process.

10 easy steps

1. Unplug the dispenser's electrical cord from its outlet. Remove the empty water bottle from the dispenser.
2. Carefully fill the reservoir with clean, boiled water.
3. Let water sit for 3 minutes to partially cool.
Always use care around hot water!
4. Wearing rubber gloves, use a clean scrub brush or cleaning pad to gently clean the reservoir and baffle.
Never use soap, cleaning fluid, steel wool or other abrasive material to clean the unit.
5. Drain the water in the dispenser completely by activating the dispensing levers on the faucets.
6. Repeat process allowing 3 minutes for water to cool.
7. Wipe the outside of the dispenser, including the faucets.
8. Drain reservoir completely. Place a new full bottle of water on top of the dispenser unit.
9. Remove air from the hot tank by activating the hot water dispenser lever until water flows freely from faucet.
10. Plug in the power cord and in less than an hour, you can enjoy hot and cold water from your clean dispenser.

6

**Specifications and Parts
Identification**



**Our Worry-Free Dispenser
Limited Warranty**

**Applies to Dispensers Provided
Rent-Free with Our Pure Savings Plans**

The water dispenser we are providing for your use with our Pure Savings Plan home delivery service is engineered and manufactured to provide years of quality and enjoyment. Should you have a problem with the dispenser, please contact us to arrange for inspection, replacement and/or repair, as we deem appropriate. This limited warranty covers defects in the dispenser's materials or workmanship for as long as you are our Pure Savings Plan home delivery customer. Services covered by this limited warranty will be performed without charge, including pick-up and delivery. Damages to the dispenser that result from: (a) use of the dispenser in a manner that is not normal of customary; (b) improper operation or misuse; or (c) accident, neglect, alteration or abuse and physical damage to the surface of the dispenser, including scratches, cracks or other damage to externally exposed parts are not covered by our limited warranty, and we must reserve the right to charge you a fee to repair any such damages. Except where prohibited or restricted by law, (1) there are no warranties, express or implied, other than as specifically set forth herein, including any implied warranties of merchantability or fitness for a particular purpose, and (2) this limited warranty does not cover incidental or consequential damages. If you terminate your Pure Savings Plan home delivery service, this limited warranty will terminate, and you must return the dispenser to us by making it available for pick-up.

**Our Two Year
Limited Warranty**

**Applies to Dispenser Purchased
from BlueTriton Brands, Inc.**

This two year limited warranty is available only to consumers who purchase this product from BlueTriton Brands, Inc. for home or office use. BlueTriton Brands, Inc. warrants that this product will be free of defects in material or workmanship under normal home and office use for two years from the date of original purchase. This warranty does not cover any damage caused by (a) use of the dispenser in a manner that is not normal or customary; (b) improper operation or misuse; or (c) accident, neglect, alteration or abuse, and physical damage to the surface of the dispenser, including scratches, cracks or other damage to externally exposed parts. Except where prohibited or restricted by law, (1) there are no warranties, express or implied, other than as specifically set forth herein, including any implied warranties, of merchantability or fitness for a particular purpose, and (2) this limited warranty does not cover incidental or consequential damages.

Troubleshooting Guide

Problems	Cause	Solution
No cold water and No hot water	Dispenser not plugged into 115 Volt electrical outlet	Verify voltage
	No power to electrical outlet	Reset circuit breakers or change fuse
Cold water not available	The cold water thermostat setting is too high	Follow cold water thermostat adjustment instructions
	Poor ventilation	Make sure dispenser is at least 4 inches from the wall
	Cold water baffle is not set properly	Secure the cold water baffle in the cold tank
	Water is exposed to direct sunlight or heat source	Move dispenser away from sunlight or heat source
Hot water not available	Excessive use of cold water	Wait 45 minutes for cold water to be restored
	Excessive use of hot water	Wait 30 minutes for hot water to be restored
	The hot water switch is in the off position	Switch to the ON position
Noisy operation	No water in hot tank	See instructions for purging air from hot tank
	The dispenser is not level	Level dispenser
Water leak (outside)	The dispenser is in contact with other equipment	Move dispenser away from other equipment
	Cracks or pin holes in bottle	Replace bottle
Water leak (inside)	Unplug dispenser and remove bottle immediately, contact Customer Service	

Electrical Specifications

115V-60Hz
Peak power consumption 5.2 Amps
Refrigeration 0.8 Amps
Heating 4.4 Amps

USER'S MANUAL

Customer Service

Arrowhead
1-800-950-9393
service.arrowheadwater.com


Deer Park
1-800-325-3337
service.deerparkwater.com

Ice Mountain
1-800-472-9888
service.icemountainwater.com

Ozarka
1-800-950-9397
service.ozarkawater.com

Poland Spring
1-800-950-9396
service.polandspring.com

Zephyrhills
1-800-950-9398
Service.zephyrhillswater.com



For use with all
Reflection and
Vision Hot and
Cold Bottled Water
Dispensers